

Designed for the Heaviest OTR/Mining Application...



INSTALLATION:

- +** Ensure that each wheels/rim is completely cleaned before the installation of *WHEEL+AID*
- +** *WHEEL+AID* will clean and remove existing corrosion and rust from the wheel/rim using the natural motion of the vehicle.
- +** Demount tire from wheel. Install recommended amount of *WHEEL+AID* before mounting tire back onto wheel.

RECOMMENDED APPLICATION AMOUNT BY TIRE:

2 Gallons [8 Liters]	3 Gallons [11 Liters]	4 Gallons [15 Liters]	5 Gallons [19 Liters]	6 Gallons [23 Liters]	8 Gallons [30 Liters]	15 Gallons [57 Liters]
12.00-24	18.00-25	18.00-33	24.00-35	24.00-49	45/65-45	37.00-57
13.00-24	21.00-25	21.00-35	33.5-33	37.5-33	27.00-49	
14.00-24	20.5-25	26.5-29	29.5-35	37.25-35	30.00-51	20 Gallons [76 Liters]
16.00-25	23.5-25	29.5-29	33.25-35	35/65-33		40.00-57
15.5-25	26.5-25	33.25-29		37.5-39	10 Gallons [38 Liters]	50/80-57
17.5-25	29.5-25	24.5-32			33.00-51	
14.9-24	16.9-28				36.00-51	25 Gallons [95 Liters]
16.9-24	18.4-28				50/65-51	ALL 63"
17.5L-24	21L-24					
19.5L-24						